

*confidence test shows a NO-GO in the
FLASH TEST ONLY. [See Figure 2-9.]*

1. At the password prompt enter the following password – **HUDSON.BAY**
2. Enter the following command – **EPI2374**, wait for "EPI ok", than power down SPU at this point. *(note: default parameters will be loaded. Call CEC if you do not wish to lose adjustments)*
3. Power up SPU. Enter Password.
4. Enter the "GET" command and note the parameter that is returned. A value must be entered for this parameter in order for the test to be successful. See parameter listing for the proper default value. (i.e. DZD=2048 ENTER). Enter WRT after every change.